

Maximum Control for Controlled Substances

CW1 Wall Mount: PIN - Proximity Card Reader - Networkable

- PIN
- Proximity Card Reader
- Heavy Duty Steel Construction
- 3 Adjustable Shelves

Manufacturer: ESSC/MedixSafe Inc. Memphis TN U.S.A MedixSafe.com

Model Numbers: There are two model numbers for the **CW1**:
The **CW1** and the **CW1-HID**.

Exterior Cabinet Dimensions: 24" High x 18" Wide x 12" Deep

Interior Cabinet Dimensions: 23-7/8" High x 17-7/8" Wide x 11-7/8" Deep

Weight: 85 lbs.

Finish: Powder Coating

Color: Black

Material: 10 gauge steel

Locking Mechanism: Single 600 lbs. lock

Voltage: 12 Volt DC current draw- 20mA idle, 130mA active

Combination PIN Pad and Proximity Card Reader: The MedixSafe

CW1 is equipped with a stand-alone networkable TCP/IP based

controller and is designed to require both an individual PIN and/or Proximity Card to gain access. All PIN/Card activity is recorded in the PIN/Card reader memory. This allows the **CW1** to store up to 3,000 users and a 50,000 event activity log. The **CW1** also features:



- **USB-host port for offline data mgmt/access**
- **Audio Visual indicators via internal speaker**
- **Bi-color LED operation indicator**
- **3 Adjustable Interior Shelves**
- **Large LCD screen**
- **MedixSafe Audit software**

Software: The MedixSafe **CW1** is an access control solution that is easy to manage from any computer. The software comes with the following features:

1. Interactive embedded help screen
2. Intuitive icons
3. Descriptive, easy-to-understand information
4. Well organized menu and programming for fast setup

Hardware: Customers existing PC or lap top.

Non Wi-Fi Communications: A TCP/IP connection will need to be provided for communications to the **CW1** for remote administration.

1-855-MEDIXSAFE
1-855-633-4972



1619 Bartlett Rd.
Memphis, TN 38134
MedixSafe.com