

Maximum Control for Controlled Substances

MS1: PIN Pad Proximity Card Reader – Networkable *** **INDUSTRIAL GRADE Wi-Fi UPGRADE AVAILABLE** ***

Manufacturer: ESSC/MedixSafe Inc. Memphis TN USA medixsafe.com

Model Numbers: There are two model numbers for the **MS1**: The **MS1** and the **MS1-HID**

Exterior Cabinet Dimensions: 7" High x 8" Wide x 10" Deep

Cabinet Weight: 15 lbs

Finish: Powder Coating

Color: Black

Material: 10 and 12 gauge steel

Locking Mechanism: Single 600 lbs lock

Voltage: 12 Volt DC current draw- 20mA idle, 130mA active



Combination PIN Pad and Proximity Card Reader: The MedixSafe **MS1** is equipped with a stand-alone networkable TCP/IP based controller and is designed to require both an individual PIN and/or Proximity Card to gain access. All PIN/Card activity is recorded in the PIN/Card reader memory. This allows the **MS1** to store up to 30,000 users and a 50,000 event activity log. The **MS1** also features:

- USB-host port for offline data mgmt/access
- Audio Visual indicators via internal speaker
- Bi-color LED operation indicator
- MedixSafe Audit software
- Large LCD screen
- Small, compact design
- Multi-language display function

Mounting: **MS1** can be mounted via 3/8 holes on bottom or customized holes for either side or top.

Software: The MedixSafe **MS1** is an access control solution that is easy to manage from any computer. The software comes with the following features:

1. Interactive embedded help screen
2. Intuitive icons
3. Descriptive, easy-to-understand information
4. Well organized menu and programming for fast setup

Hardware: Customers existing PC or laptop.

Non Wi-Fi Communications: A TCP/IP connection will need to be provided for communications to the **MS1** for remote administration.

1-855-MEDIXSAFE
1-855-633-4972



1619 Bartlett Rd.
Memphis, TN 38134
MedixSafe.com