

Maximum Control for Controlled Substances

MX2: Biometrics - PIN Pad - Proximity Card Reader - Networkable *** INDUSTRIAL GRADE *Wi-Fi* UPGRADE AVAILABLE ***

Manufacturer: ESSC/MedixSafe Inc. Memphis TN U.S.A MedixSafe.com

Model Numbers: There are two model numbers for the **MX2**:
The **MX2** and the **MX2-HID**.

Exterior Cabinet Dimensions: 14" High x 12" Wide x 16" Deep

Interior Cabinet Dimensions: 13-7/8" High x 11-7/8" Wide x 15-7/8" Deep

Weight: 40 lbs, 43 lbs packaged

Finish: Powder Coating

Color: Black

Material: 10 and 12 gauge steel

Locking Mechanism: Single 600 lbs lock

Voltage: 12 Volt DC current draw 20mA idle 130mA active

Combination Biometrics, PIN Pad and Proximity Card Reader:

The MedixSafe **MX2** is a truly revolutionary and compact narcotics cabinet. It is equipped with a stand-alone networkable TCP/IP based controller and is designed to require combinations of fingerprint, PIN and/or Proximity Cards to gain access. This allows the **MX2** to store up to 1,500 users and a 50,000 event activity log. The **MX2** can also connect directly to a wireless communication device at 100 Mbps which allows it to have fingerprint additions/deletions and user activity uploaded/downloaded without having to go directly to the ambulance. Hardwiring to an existing network for additional office/storage locations is also an option. **The MX2 cannot be compromised just by watching someone else enter their PIN number!**

Mounting: **MX2** unit mounting via 3/8 holes on bottom or customized holes for either side or top.

Software: The MedixSafe **MX2** is an access control solution that is easy to manage from any computer. The software comes with the following features:

1. Interactive embedded help screen
2. Intuitive icons
3. Descriptive, easy-to-understand information
4. Well organized menu and programming for fast setup

Hardware: Customers existing PC or laptop.

Non Wi-Fi Communications: A TCP/IP connection will need to be provided for remote administration and communication to the **MX2**



1-855-MEDIXSAFE
1-855-633-4972

MEDIXSAFE™

1619 Bartlett Rd.
Memphis, TN 38134
MedixSafe.com