

# Maximum Control for Controlled Substances

## **S2 StorageSafe:** Biometrics - PIN - Proximity Card Reader

- Reads Fingerprints / PINs
- Highly Accurate Optical Sensor
- Option for Smart Cards
- Heavy Duty Steel Construction
- 2 Separate Compartments
- Built-in TCP/IP, Serial, and USB

**Manufacturer:** ESSC/MedixSafe Inc. Memphis TN U.S.A [MedixSafe.com](http://MedixSafe.com)

**Model Numbers:** There are two model numbers for the **S2**:  
The **S2** and the **S2-HID**.

**Exterior Cabinet Dimensions:** 52 1/2" (w/caster wheels) High x 40" Wide x 29 1/2" Deep

**Weight:** 400 lbs

**Finish:** Powder Coating

**Color:** Black

**Material:** 10 gauge steel

**Locking Mechanism:** Single 1,000 lbs lock per door

**Voltage:** 12 Volt DC current draw 80mA idle 500mA active

### **Combination Biometrics, PIN Pad and Proximity Card Reader**

**Reader:** The MedixSafe **S2** is a truly revolutionary narcotics storage cabinet. It is equipped with a stand-alone networkable TCP/IP based controller and is designed to require combinations of fingerprint, PIN and/or Proximity Cards to gain access. This allows the **S2** to store up to 1,500 users and a 50,000 event activity log. The **S2** can also connect directly to a wireless communication device and allows it to have fingerprint additions/deletions and user activity uploaded/downloaded without having to go directly to the cabinet. Hardwiring to an existing network for additional office/storage locations is also an option. **The S2 cannot be compromised just by watching someone else enter their PIN number!**

**Software:** The MedixSafe **S2** is a web-based access control solution that is easy to manage from any computer running a standard web browser. The embedded web browser interface comes with the following features:

1. Interactive embedded help screen
2. Intuitive icons
3. Descriptive, easy-to-understand information
4. Well organized web menu and programming for fast setup

**Hardware:** Customers existing PC or lap top.

**Remote Communications:** A TCP/IP connection will need to be provided for remote administration and communication to the **S2**



1-855-MEDIXSAFE  
1-855-633-4972

**MEDIXSAFE™**

1619 Bartlett Rd.  
Memphis, TN 38134  
[MedixSafe.com](http://MedixSafe.com)